
(1)	DOORS 14 5/8	20 3/4	Slab Door	3/4 Panel St HP
(1) (1) (1) (1) (1) (2)	PANEL STO 9 9 13 1/2 8 1/4 8 1/4 8 1/8	CK 21 21 21 13 1/2 13 1/2 13 3/8	Unfinished Left End Unfinished Right End Unfinished Back Top Bottom Adjustable Shelf	3/4 Handy Panel 3/4 Handy Panel 3/4 Handy Panel 3/4 Handy Panel 3/4 Handy Panel 3/4 Handy Panel
(2) (1)	HARDWARE 1 1 1/4	2 1/2 1 1/4	Hinge Door Pull	Blum 110 Brass Knob

CABINET # 1 - W152109

15 x 21 x 9 ( 1 )





## **Garage-Cabinet-Plans.com**


This plan requires 2 "handy panels" that you can purchase at your local home improvement store.

Follow the plywood cutting diagrams, then assemble the parts using pocket screws.

	CABI	NET # 1 - W152109		Seth Townsend	
L.Reveal = 3/16	R.Reveal = 3/16	T.Reveal = 1/8	B.Reveal = 1/8	Free Plan	
		H.Reveal = 1/8	V.Reveal = 1/8	Handy Panel Wall Cabinet Plan	
T.Scribe = 0	B.Scribe = 0			Room # 1 (Room 1) - Wall # 1	
Left End = Unfinished	Right End = Unfinished	Back = Unfinished			
			Date :		







## Garage-Cabinet-Plans.com

Use your Kreg-Jig to cut pocket holes and assemble with pocket screws.

> Keep pocket holes to the outside of the box for a nice clean interior.



Seth Townsend, Cabinetmaker, LLC Marietta, GA 30068 All dimensions given are subject to verification on job site and adjustment to fit job conditions. This is an original design and must not be released or copied unless applicable fee has been paid or job order placed.

Hand	<sup>a</sup> Handy Panel Wall Cabinet Plan				
Size:	Drawing Number:		Revision:		
Date:		Sheet			

Title

#### Garage-Cabinet-Plans.com

This plan requires 2 24" x 48" plywood panels (Handy Panels) - https://garage-cabinet-plans.com/handy-panels

Follow this procedure plan:


- Cut parts according to cutting diagrams
- Drill pocket holes in top, bottom and back panels
- Drill shelf pin holes in end panels
- Assemble the case
- Add the door and hinges
  (for this project, it's easy to get and use these hinges:
   https://garage-cabinet-plans.com/liberty-hinges )

Follow all the construction methods here:

- https://garage-cabinet-plans.com/category/how-to-build-garage-cabinets/


Seth Townsend, Cabinetmaker, LLC Marietta, GA 30068 All dimensions given are subject to verification on job site and adjustment to fit job conditions. This is an original design and must not be released or copied unless applicable fee has been paid or job order placed.

Title: Hand	Handy Panel Wall Cabinet Plan				
Size:	Drawing Number:		Revision:		
Date:		Sheet			



- A To get started, rip this first panel at 14 5/8", the cross-cut the piece at 21" and 20 3/4". Rip the back to size at 13 1/2"
- B Rip the remaining piece at 8 1/4", then cross-cut the top and bottom to size at 13 1/2". Cut the adjustable shelf from the remaining material.

# Garage-Cabinet-Plans.com



Seth Townsend

Sample Plan - Sample Garage Wall Cabinet Plan

Date : 02-02-2013



A - Cross-cut this panel at 21 inches, then rip the end panels to width at 9 inches

Cut the adjustable shelf from the remaining piece

# Garage-Cabinet-Plans.com

Seth Townsend

Sample Plan - Sample Garage Wall Cabinet Plan

Date : 02-02-2013